

1:1 Print! Check dimension by controlling the gauge!

## KiCAD Footprints of some potentiometers and trimmers from the file

Potentiometer\_RevB\_02Aug2010.mod

Author: Bernd Wiebus / Uedem / Germany / 02th Aug 2010

Licence: CC-Zero / Public Domain


NO RESTRICTION ! NO WARRANTY!

<http://creativecommons.org/>



For suggestions  
and improvements  
please contact  
me at  
[bernd.wiebus@gmx.de](mailto:bernd.wiebus@gmx.de)

File: Potentiometer_Part1_RevB_02Aug2010.kicad_pcb	
Sheet:	
Title:	
Size: A4	Date:
KiCad E.D.A.	Rev: 1/1



1:1 Print! Check dimension by controlling the gauge!

## KiCAD Footprints of some potentiometers and trimmers from the file

Potentiometer\_RevB\_02Aug2010.mod

Author: Bernd Wiebus / Uedem / Germany / 02th Aug 2010

Licence: CC-Zero / Public Domain

NO RESTRICTION ! NO WARRANTY!

<http://creativecommons.org/>

For suggestions  
and improvements  
please contact  
me at  
[bernd.wiebus@gmx.de](mailto:bernd.wiebus@gmx.de)



File: Potentiometer_Part2_RevB_02Aug2010.kicad_pcb	
Sheet:	
Title:	
Size: A4	Date:
KiCad E.D.A.	Rev: 1/1